

Specific Heat Capacity of Metals

PHYS 442

YingXue Du(Christie)

November 16, 2015

Date Performed: November 16, 2015

Partners: Whole class

Instructor: Dr. Schultz

1 Objective

The objective of this experiment is to measure the specific heat capacity of three different samples of metal and to compare those with the accepted values. The samples consist of three unknown metals.

2 Definitions

Heat Heat is the measure of the internal kinetic energy of a substance.

Temperature Temperature is a measure of the kinetic energy of a particle. It is the degree or intensity of heat in a substance. Celcius is a unit of temperature. One degree Celcius represents the temperature change of one gram of water when 2.39×10^{-5} Joules of heat is added to it.

Specific Heat Capacity The specific heat capacity is the energy transferred to one kilogram of substance causing its temperature to increase by one degree Celcius.?

Thermal Equilibrium Thermal equilibrium is a condition where two substances in physical contact with each other exchange no net heat energy. Substances in thermal equilibrium are at the same temperature.

3 Theory

The change in the internal energy of an object or substance is equal to the product of the mass and the specific heat capacity and the change in temperature.

$$\Delta U = mC_p\Delta T$$

When water and the metal samples are in thermal equilibrium the change in heat of the water is equal in magnitude to the change in heat of the metal.

$$\Delta U_{metal} = \Delta U_{water}$$

From this relationship we may derive a formula for the specific heat capacity of the metal sample given the mass of metal, mass of water, change in temperature of the water, change in temperature of the metal and the specific heat capacity of water.

$$m_{metal}C_{metal}\Delta T_{metal} = m_{water}C_{water}\Delta T_{water}$$

$$C_{metal} = \frac{m_{water}}{m_{metal}} \frac{\Delta T_{water}}{\Delta T_{metal}} C_{water}$$

4 Materials

- Kettle
- Three unknown metals
- styrofoam cups
- graduated cylinder
- scale
- thermometer
- tongs
- flask of water

5 Method

- a. Weigh the samples and record
- b. Measure 350 ml of water in graduated cylinder and transfer to styrofoam cup
- c. Measure the initial temperature of the water
- d. Boil water and add metal samples to kettle
- e. Use tongs to transfer a sample to the cup with water
- f. Place thermometer in cup, cover it, stir and record equilibrium temperature
- g. Repeat steps b-f for each sample

6 Data

Metal	Mass Metal	Mass Water	Temp Water Initial	Temp Final
Cube	90.6 g	350g	20.5 Celcius	24.5 Celcius
Short Bar	64.1 g	300g	20.9 Celcius	22.5 Celcius
Long Bar	203.0 g	350g	20.8 Celcius	24.8 Celcius

Table 1: Experimental data

Material	Specific Heat Capacity
Water	4180 J/kg. $^{\circ}$ C
Aluminum	900 J/kg. $^{\circ}$ C
Zinc	380 J/kg. $^{\circ}$ C
Copper	387 J/kg. $^{\circ}$ C
Iron	452 J/kg. $^{\circ}$ C
Steel	452 J/kg. $^{\circ}$ C
Lead	128 J/kg. $^{\circ}$ C
Silver	230 J/kg. $^{\circ}$ C

Table 2: Known specific heat capacities

7 Example Calculations

This is the calculation for the specific heat capacity of cube.

$$C_{metal} = \frac{m_{water}}{m_{metal}} \frac{\Delta T_{water}}{\Delta T_{metal}} C_{water}$$
$$\Delta T_{water} = 24.5 - 20.5 = 4\text{Celcius}$$
$$\Delta T_{metal} = 100 - 24.5 = 73.5\text{Celcius}$$
$$C_{metal} = \frac{0.350\text{kg}}{0.0906\text{kg}} \frac{4\text{Celcius}}{73.5\text{Celcius}} 4180 \text{ J/kg}\cdot^{\circ}\text{C} = 878 \text{ J/kg}\cdot^{\circ}\text{C}$$

The percent error is calculated as follows.

$$Error = \frac{900 - 878}{900} = 0.02\%$$

8 Results

Material	Measured C_p	Percent Error
Cube	878 J/kg. $^{\circ}$ C	48.3%
Short Bar	277.7 J/kg. $^{\circ}$ C	26.9%
Long Bar	383.35 J/kg. $^{\circ}$ C	0.94%

Table 3: Calculated specific heat capacities

9 Discussion of Error

The Final temperature of the metals are not exactly 100 celcius, which may be the reason that the error is huge.

10 Conclusion

Since there are some errors, the data collected may not be the exact specific heat capacity of the metal, but by comparing and adding the range of error, we can still find out the material of the metal. The Cube is Aluminium. The short Bar is Zinc. The long bar is the copper.

References